

Date of Deposit: October 31, 2001
Express Mail Label No. EF294919736US

Signature Patrice Uchno Leland
Name: Patrice L. Uchno Leland

1

GP-301388

VEHICLE REMOTE STARTING SYSTEM SHUTOFF

TECHNICAL FIELD

[0001] The present invention relates to remote starting systems for vehicles, and more particularly to a shutoff system and method for vehicle remote starting systems.

5

BACKGROUND OF THE INVENTION

[0002] Vehicles utilizing internal combustion engines and diesel engines should be started and warmed up before they are driven. Warming the engine is particularly important in cold weather conditions because the vehicles could stall if they are improperly warmed up before driving. In addition, damage to the engine may occur if the engine is run at higher rpms while the engine is cold. In many vehicles, it is advisable to warm the engine for a few minutes before driving. Most drivers fail to allow the engine sufficient time to warm up the vehicle prior to driving. Usually, the vehicle is started and driven immediately. As a result, the life of the engine is reduced.

[0003] In cold weather, it is inconvenient for the driver to sit in the cold vehicle as the engine warms up. When leaving for work in the morning, some drivers start the vehicle and leave the vehicle unattended while it is warming up. This practice is inconvenient since the driver must endure the cold weather twice. During the day, if the vehicle is allowed to sit long enough to cool down to the cold outside ambient temperature, drivers often fail to allow the engine to warm up before driving the vehicle again.

[0004] Entering a vehicle in hot or cold temperature extremes is an unpleasant experience for the driver and/or passengers. In the heat of

10001238 10101
10001238 10101

summer or the cold of winter, the climate control system may take several minutes to heat or cool the passenger compartment to a comfortable temperature. In cold weather, the vehicle occupants must endure the cold temperatures while the climate control system heats the passenger

5 compartment. In hot weather conditions, the temperature of the compartment often rises significantly higher than the outdoor temperature. The vehicle occupants often begin to perspire before the passenger compartment cools to a comfortable temperature. When frost or fog coats the front or rear windows, it often takes a few minutes until the windows can

10 be cleared. The driver must wait in the vehicle until the car defroster sufficiently clears the windows before driving safely.

[0005] In an effort to eliminate some of the above-identified problems, remote starting systems for automobile engines were developed. Representative systems are disclosed in U.S. Patent Nos. 4,080,537 to

15 Bucher; 4,236,594 to Ramsperger; 4,392,059 to Nespor; 4,446,460 to Tholl et al; 4,598,209 to Carlinghouse; 4,606,307 to Cook; 5,000,139 to Wong; 5,054,059 to Scott et al; 5,184,584 to Cantrell; 5,656,868, to Gottlieb et al; 5,617,819 to Dery et al; 5,689,142 to Liu; and 5,757,086 to Nagashima.

[0006] These systems generally utilize a portable transmitter that is

20 carried by the driver to remotely start the vehicle; however, other devices maybe employed. The transmitter generates a radio frequency signal that is received by a remote starting device that is associated with the vehicle. In more simple systems, such as 6,147,418 to Wilson, the driver must manually set the defroster, heat or other device prior to leaving the car before the

25 remote start. More complex systems such as 5,673,017 to Dery et al. allow the climate control system, defroster and other vehicle systems to be indirectly adjusted using the transmitter.

[0007] Typically, the transmitter must be located within a certain distance from the vehicle – such as 100-300 yards. The transmitters are

30 either one-way or two-way control systems. One-way systems do not

10001238-10101
TOTI 8820001

typically provide any indication or feedback to the transmitter regarding the status of the engine and/or the accessories. Two-way systems, such as pager systems, sometimes provide an indication that the engine and/or the accessories have been successfully turned on.

5 **[0008]** Generally, the transmitter of the remote starting system operates in a manner that is similar to keyless entry systems. When the driver presses a start button on the transmitter, the transmitter generates a start signal that typically includes an encoded start message. The receiver decodes the start message, a controller checks certain conditions (such as
10 whether the vehicle is already running and in park for automatic transmissions), and the controller sends a start signal to an engine control module.

[0009] Some of the remote starting systems such as Re. 30,686 to Bucher or 5,942,988 to Snyder et al. can be deactivated or shut off by
15 depressing the brake or opening the hood. Unfortunately, the driver often inadvertently bumps the brake pedal upon entering the vehicle, which turns the vehicle off and requires the vehicle to be restarted. In addition, if a passenger in the vehicle wants to shut off the engine, the brake pedal is not readily accessible from the front or rear passenger seats.

20

SUMMARY OF THE INVENTION

[0010] A remote starting system shutoff apparatus and method according to the present invention for a vehicle includes a vehicle power plant and a remote starting system that is connected to the vehicle power
25 plant. A transmitter actuates the remote starting system to start the vehicle power plant. A switch that is located in the vehicle compartment has first and second positions. When the switch is in the first position, the vehicle power plant can be started using the transmitter. When the switch is in the second position, the vehicle power plant cannot be started using the
30 transmitter. The switch is preferably the vehicle hazard switch.

[0011] In other features of the invention, after the vehicle power plant is started, the remote starting system turns the vehicle power plant off if the hazard switch transitions from the first position to the second position. The vehicle power plant is preferably selected from the group of internal combustion engines, diesel engines, hybrids and fuel cells.

[0012] A remote starting system shutoff apparatus and method for a vehicle according to another aspect of the invention includes a vehicle power plant and a remote starting system that is connected to the vehicle power plant. A transmitter actuates the remote starting system to start the vehicle power plant. A switch that is located in the vehicle compartment has first and second positions. After the vehicle power plant is started, the remote starting system turns the power plant off if the switch transitions from the first position to the second position. The switch is preferably a hazard switch.

[0013] Further areas of applicability of the present invention will become apparent from the detailed description provided hereinafter. It should be understood that the detailed description and specific examples, while indicating the preferred embodiment of the invention, are intended for purposes of illustration only and are not intended to limit the scope of the invention.

BRIEF DESCRIPTION OF THE DRAWINGS

[0014] The present invention will become more fully understood from the detailed description and the accompanying drawings, wherein:

[0015] FIG. 1 is a perspective view illustrating the operation of a remote starting system for a vehicle;

[0016] FIG. 2A is a block diagram illustrating a remote starting system for a vehicle that includes a shutoff switch according to the invention;

[0017] FIG. 2B is a block diagram of the presently preferred remote starting system shutoff for a vehicle that employs the vehicle hazard switch;

[0018] FIG. 2C is a block diagram of a presently preferred controller; and

[0019] FIG. 3 illustrates steps for disabling the remote starting system via the hazard switch shown in FIG. 1.

5

DESCRIPTION OF THE PREFERRED EMBODIMENTS

[0020] The following description of the preferred embodiment(s) is merely exemplary in nature and is in no way intended to limit the invention, its application, or uses.

10 **[0021]** Referring now to FIG. 1, a vehicle operator or passenger 10 actuates a transmitter 12 to generate a starting signal 16 that is transmitted to a vehicle 20. The starting signal 16 starts a power plant of the vehicle 20. For example, the transmitter 12 can be actuated from the comfort of the home of the vehicle operator 10.

15 **[0022]** Referring now to FIG. 2A, for purposes of clarity reference numerals from FIG. 1 have been used where appropriate to identify similar elements. The transmitter 12 is shown to include a start button 22-1 and other keyless entry buttons such as a lock button 22-2, unlock button 22-3, trunk button 22-4, and panic button 22-5. The transmitter 12 typically
20 includes an antenna 24, and the starting signal 16 is a radio frequency signal. Skilled artisans will appreciate that the transmitter may include other buttons, functions, displays, or other input/output interfaces.

[0023] The vehicle 20 includes a power plant 30 that is connected to a remote starting system 34. The remote starting system 34 includes a
25 receiver 36 and a controller 38. The controller 38 is preferably connected to a vehicle data bus 40, the receiver 36, and the power plant 30. The vehicle 20 includes a switch 50 that is located in the passenger compartment and is connected to the vehicle data bus 40 and/or to the controller 38. Optional connection methods are shown in dotted lines in FIGs. 2A and 2B. In a
30 preferred embodiment, the switch 50 is a hazard switch 50' of the vehicle 20

1001233 110101

as is shown in FIG. 2B. The switch 50 and the hazard switch 50' preferably have at least two positions or states. The power plant 20 can be an internal combustion engine, a diesel engine, a fuel cell, or a hybrid.

[0024] Referring now to FIG. 2C, a presently preferred

5 implementation of the controller 38 is illustrated in further detail and includes a processor 60, memory 62 such as read only memory (ROM), random access memory (RAM), or other suitable electronic storage, and an input/output (I/O) interface 66. The I/O interface 66 is connected to the vehicle databus 40 and/or to the switch 50 or the hazard switch 50'.

10 **[0025]** Referring now to FIG. 3, steps for operating the controller 38 are illustrated in further detail. Control begins with step 100. In step 102, the controller 38 determines whether there is a remote starting request. Step 102 may be preceded by a determination of whether the power plant 30 of the vehicle 20 is currently running. In a preferred mode, after the remote
15 starting request, the controller 38 runs the vehicle 20 for a first predetermined period (for example, for 10 minutes) and then shuts down the engine. Once the power plant 30 of the vehicle 20 is running, if the remote starting system 34 is triggered again, the controller 38 resets the first predetermined period once (for a maximum of 2x the first predetermined
20 period). The reset mode may be inhibited initially (for example, for 30 seconds) when the first remote starting request is received to prevent false or inadvertent resets.

[0026] If the vehicle is not running and a remote starting request has been received, the controller 38 determines whether the switch 50 or 50' is
25 in an active position in step 104. If the switch is not active, control continues with step 106 where the controller 38 activates the remote starting of the vehicle power plant 30. In step 108, the controller 38 reads the status of the switch 50 or 50' either directly or through the vehicle data bus 40. If the switch 50 or 50' is in an active position as determined in step 110,
30 remote starting is disabled and the vehicle power plant 30 is turned off in

10004288-10101

step 112. If the switch 50 or 50' is not active as determined in step 110, control continues from step 110 back to step 108.

[0027] In use, the vehicle operator 10 uses the transmitter 12 to start the vehicle 20 remotely. For example, the vehicle operator 10 starts the vehicle from inside a building or home as is shown in FIG. 1. If the switch 50 or 50' is not active, the remote starting system 34 starts the vehicle power plant 30. When the vehicle operator 10 or passenger wants to shut off the vehicle power plant 30, the vehicle operator 10 or passenger simply toggles the switch 50 or 50' to shut the vehicle power plant 30 off. Still other methods and/or devices for shutting off the engine may be employed in addition to the switch 50 or 50'. If the vehicle operator 10 attempts to start the vehicle using the transmitter 12 while the switch 50 or 50' is active, the remote starting system 34 is deactivated and the transmitter 12 cannot start the vehicle.

[0028] As can be appreciated by skilled artisans, the use of the hazard switch 50' in the presently preferred embodiment is a particularly cost-effective mechanism for disabling or shutting off the remote starting system 34'. The hazard switch 50' is easily accessible by both drivers and passengers. The use of the hazard switch 50' provides an existing switch with common operation across all conventional vehicles. The use of the existing switch saves a significant amount of money that would otherwise be spent on a dedicated switch. In addition, the use of the existing hazard switch 50' also eliminates vehicle wiring and interfacing with a controller that would be required for a separate switch.

[0029] Those skilled in the art can now appreciate from the foregoing description that the broad teachings of the present invention can be implemented in a variety of forms. Therefore, while this invention has been described in connection with particular examples thereof, the true scope of the invention should not be so limited since other modifications will become

4001288-10104

apparent to the skilled practitioner upon a study of the drawings, the specification and the following claims.

10001238 10101